Product data sheet

Subminiature connectors



Product description Snap-In IP40 Male cable connector, Contacts: 5, 3.6 mm, unshielded, solder, IP40


Area Snap-In IP40 series 719
Part no. 09 9789 00 05

Illustration

Scale drawing

Contact arrangement (Plug-in side)







You can find the assembly instructions on the next page.

Technical data

General features

Part no.	09 9789 00 05
Connector design	Male cable connector
Version	Connector pin straight
Connector locking system	snap-in
Termination	solder
Degree of protection	IP40
Cross-sectional area	0.25 mm ² / AWG 24
Cable outlet	3.6 mm
Temperature range from/to	-25 °C / 70 °C
Tightening torque sleeve	0.2 Nm
Mechanical operation	> 100 Mating cycles
Weight (g)	0.90
Customs tariff number	85369010

Electrical parameters

Rated voltage	60 V
Rated impulse voltage	800 V
Rated current (40 °C)	3,0 A
Insulation resistance	$\geq 10^{10} \Omega$
Pollution degree	1
Overvoltage category	II
Insulating material group	III

Product data sheet

Subminiature connectors



Product description Snap-In IP40 Male cable connector, Contacts: 5, 3.6 mm, unshielded, solder, IP40

Area Snap-In IP40 series 719
Part no. 09 9789 00 05

EMC compliance unshielded

Material

Housing material	PA
Contact body material	PA
Contact material	CuZn (brass)
Contact plating	Au (gold)
REACH SVHC	CAS 7439-92-1 (Lead)
SCIP number	SCIP-number not available

Classifications


eCl@ss 11.1	27-44-01-09
ETIM 7.0	EC003569

Declarations of conformity

Low Voltage Directive	2014/35/EU (EN 60204-1:2018;EN 60529:1991)

Assembly instructions

- 1. Bead sleeve to cable.
- 2. Dismantle cable to 9 mm length.
- 3. Strip and solder single wires.
- 4. Screw on sleeve.



Product data sheet

Subminiature connectors



Product description Snap-In IP40 Male cable connector, Contacts: 5, 3.6 mm, unshielded, solder, IP40

Area Snap-In IP40 series 719
Part no. 09 9789 00 05

General Disclaim Notice

The connectors have been developed for applications in plant engineering, control and electrical equipment construction. The user is responsible for checking whether the connectors can also be used in other areas of application.