
## Retro-reflective photoelectric sensor

## PRK3CA Autokollimation







EN

## Sensor adjustment (teach) via teach button

The sensor is factory-adjusted for maximum operating range. The teach procedure is only necessary if the sensor does not switch when an object enters the light beam.

(1) Standard teach (low sensitivity)		(2) Sensitive teach (increased sensitiv- ity)	
Clear the light path before teaching!			
1	Hold down the teach button (2 to 7 s) until the yellow and green LEDs flash simultaneously.	1	Hold down the teach button (7 to 12 s) until the yellow and green LEDs flash alternately.
2	Release teach button – ready.	2	Release teach button – ready.
The sensor switches when approx. half of the light beam is covered by the ob- ject.		Unlike the standard teach mode, the sensor switches when a considerably smaller part of the light spot is covered.	
Device settings are stored fail-safe.			

(3) Teach at max. operating range (fac- tory setting)		(4) Set switching behavior (light/dark switching)	
Obstruct the light path before teaching!		When the function is activated, the switching output is always inverted rela- tive to the previously set state.	
1	Hold down the teach button (2 to 7 s) until the yellow and green LEDs flash simultaneously.	1	Hold down the teach button longer than 12 s until only the green LED flashes. LED ON: switching output now light switching (output active if light path clear) LED OFF: switching output now dark switching (output active if object in light path)
2	Release teach button – ready.	2	Release teach button – ready.
The sensor now operates with the maxi- mum function reserve/operating range.		Note: The yellow LED is not dependent on the switching behavior setting and always indicates light switching in nor- mal operation.	
Device settings are stored fail-safe.			

## Sensor adjustment (teach) via teach input (pin 2)

This device setting is only available for sensors in the PRK3C.A3/...T... variant.

#### NOTICE

The following description applies to PNP switching logic!

Signal level LOW ≤ 2V

Signal level HIGH  $\geq$  (U<sub>B</sub>-2V)

With the NPN models, the signal levels are inverted!

## 1

#### Standard teach (low sensitivity)

- A Standard teach (low sensitivity) is performed
- B Teach button is locked
- C Teach button may now be operated again

# 2

#### Sensitive teach (increased sensitivity)

- A Sensitive teach (increased sensitivity) is performed
- B Teach button is locked
- C Teach button may now be operated again

# 3

#### Light switching logic

Switching outputs are light switching, i.e., outputs are active, when there is no object currently in the light path.

With antivalent switching outputs: OUT 1 (pin 4) light switching, OUT 2 (pin 2) dark switching.



#### Dark switching logic

Switching outputs are dark switching, i.e., outputs are active, when there is an object currently in the light path.

With antivalent switching outputs: OUT 1 (pin 4) dark switching, OUT 2 (pin 2) light switching.

EN

## Locking the teach button via the teach input

# 5

This device setting is only available for sensors in the PRK3C.A3/...T... variant (teach input via pin 2).

A static high signal (≥ 20ms) at the teach input locks the teach button on the sensor if required, such that no manual operation is possible (e.g., protection from erroneous operation or manipulation).

If the teach input is not connected or if there is a static low signal, the button is unlocked and can be operated freely.



- A Diaphragm diameter ≥ 3 mm
- B Typ. application range 0 ... 1 m

## IO-Link interface

Sensors in the PRK3C.../L... variant have a dual-channel architecture. The IO-Link interface is available in accordance with specification 1.1.2 (July 2013) on pin 4 (OUT 1). You can easily, quickly and economically configure the devices via the IO-Link interface. Furthermore, the sensor transmits the process data via the IO-Link interface and makes diagnostic information available through it. Parallel to the IO-Link communication, the sensor can output the continuous switching signal for object detection on OUT 2. The IO-Link communication does not interrupt this signal.

	NOTICE	
6	In the <i>Sensor Studio</i> configuration software, the following applies with regard to the designations: Q1 = OUT 1, Q2 = OUT 2.	
The sensors offer no data retention and no ISDU support. The device can only be identified via VendorID and DeviceID.		

### IO-Link identification

VendorID dec/hex	DeviceID dec/hex	Device
338/0x152	2118/0x000846	PRK3C.A3/LP

### IO-Link process data

#### Device output data

Data bit	Assignment	Meaning
0	Switching output Q1 (OUT 1)	0 = inactive, 1 = active
1	Warning output autoCon- trol	0 = no warning, 1 = warning
2	Sensor operation	0 = off, 1 = on Sensor operation off when detection is not possible (e.g during the teach event).
3	Not assigned	Free
4	Not assigned	Free
5	Not assigned	Free
6	Not assigned	Free
7	Not assigned	Free

#### Device input data

Data bit	Assignment	Meaning
0	Deactivation	0 = transmitter active, 1 = transmitter in- active
1	Not assigned	Free
2	Not assigned	Free
3	Not assigned	Free
4	Not assigned	Free
5	Not assigned	Free
6	Not assigned	Free
7	Not assigned	Free

## Device-specific IODD

At www.leuze.com in the download area for IO-Link sensors you will find the IODD zip file with all data required for the installation.

EN

### IO-Link parameters documentation

The complete description of the IO-Link parameters can be found in the \*.html files. Double-click on a language variant:

- German: \*IODD\*-de.html
- English: \*IODD\*-en.html

### Functions configurable via IO-Link

PC configuration and visualization is performed comfortably with the USB-IO-Link Master SET US2-IL1.1 (part no. 50121098) and the *Sensor Studio* configuration software (in the download area of the sensor at www.leuze.com).

Function block	Function	Description
Configuration	Logical function of Q2	If the function Q2 = <i>switching output</i> is selected, the switching function corresponds to the current setting which was selected via the L/D changeover. If Q2 = <i>inv. switching output</i> is selected, the switching behavior of the output is inverted.
	Key Lock	On disables the teach button on the sensor.
	L/D switching	In the factory setting, outputs Q1 and Q2 are antivalent switching outputs: – Light switching: Q1 = light switching, Q2 = dark switching. – Dark switching: Q1 = dark switching, Q2 = light switching.
	Switching delay	On activates the internal time function.
	Function selection of the switching de- lay	Activation of a suitable switching delay is possible. It is not possible to combine switching delays.
	Time base of the switching delay	Possibility of selecting a time base.
	Factor for the time base of the switch- ing delay	To adapt the time base, it is multiplied by the entered factor. Only whole-number fac- tors from 1 to 15 are permitted.

Function block	Function	Description
<b>Commands</b> The first four commands correspond to the functions	Sensitive teach for the detection of a transparent ob- ject (e.g. empty sin- gle bottle)	Clear the light path before activation.
which can be performed at the sensor us- ing the teach button or the remote teach function.	Standard teach for the detection of a partially transpar- ent object (e.g. bot- tle made of colored glass)	Clear the light path before activation.
Turiotion.	Light switching	
	Dark switching	
	Switch the process data display mode to analog value	Activate to display diagrams on the <i>Process</i> tab when using <i>Sensor Studio</i> configuration software.